

# A. B. DICK 8800 T-51® SWING-AWAY® T-HEAD

## Frequently Used Part Numbers


### Rollers

X07-51110	Form Roller, Soft
XSA-070288SW	Metering Roller Assy., Hard (Roller, shaft, snap ring, collar, roll pin)
X07-0322NS	Pan Roller, Soft
XSA-07001	Upper Intermed. Roller, Soft
X07-51151	Lower Intermed. Roller, Soft
X07-0430	Oscillator Roller, Hard

### Miscellaneous

XSA-1136	Water Pan Assy. (w/ pan bolts)
X99-28	Water Pan Hose
XSA-9905	Water Bottle (w/cap)
X99-61	Wash Up Bottle
X88-81	Installation Manual

**FAX YOUR ORDER  
TO ACCEL TOLL FREE!  
1 (800) 365-6510**



#### Adjustments

- a. Metering to Pan
- b. Form to Plate

#### Roller Description

P	=	Pan, Soft
M	=	Metering, Hard
UI	=	Upper Intermediate
LI	=	Lower Intermediate
O	=	Oscillator, Hard
F	=	Form, Soft