

# DIDDE 11, 17 OLD STYLE

## Frequently Used Part Numbers

These part numbers apply to units before serial number 9604-18619.

### Rollers

X07-0133	Form Roller, Soft
X07-0337	Pan Roller, Hard
X07-0429	Oscillator Roller, Hard
XSA-070238	Metering Roller Assy., Soft (Roller, shaft, bearings, snap rings)
XSA-070531	Intermed. Assy., Soft (Roller, shaft, bearings, collar)

### Side Frames

Note: each side frame requires (1) X06-108 bearing.

XSA-010111	OPS Side frame
XSA-010112	NOPS Side frame


### Bearings

X06-108	Sealed Ball Bearing, Side Frame (2 per dampener)
X06-107	Sealed Ball Bearing, Pan Shaft (2 per dampener)
X06-103	Sealed Ball Bearing, Pivot (2 per dampener)
X06-100	Sealed Ball Bearing, Form Roller (2 per dampener)

### Miscellaneous

XSA-9903	Metering Thumb Screw Assy. (Thumb screw, ratchet gear, set screw)
X09-0101	Compression Spring (2 per dampener)
XSA-1138	Water Pan Assy. (w/ pan bolts)
X21-18	Splash Shield
X99-61	Wash Up Bottle
X88-62	Installation Manual

**FAX YOUR ORDER  
TO ACCEL TOLL FREE!  
1 (800) 365-6510**



#### Adjustments

- a. Form to Plate
- b. Form to Oscillator
- c. Metering to Intermediate
- d. Pan to Metering

#### Roller Description

- F = Form, Soft
- O = Oscillator, Hard
- I = Intermediate
- M = Metering
- P = Pan