

# HAMADA 661/662 SATELLITE

## Frequently Used Part Numbers

### Rollers

X07-0120	Form Roller, Soft
X07-0319	Pan Roller, Soft
X07-0417	Oscillator Roller, Hard
XSA-070218NS	Metering Roller Assy., Hard (Roller, shaft, collars)

### Side Frame Assemblies

XSA-010113	OPS Side Frame Assy. (Side frame w/ bearings)
XSA-010114	NOPS Side Frame Assy. (Side frame w/ bearings)

### Gears

XSA-03211538	Form Gear Assy. (Gear w/ clutch bearing)
XSA-03211530	Pan Gear Assy. (Gear w/ clutch bearing)
XSA-03210526	Idler Gear Assy. (Gear, spool, bushing, bolt, washers)


### Bearings

(After serial #9211-08613)	
X06-108	Sealed Ball Bearing, Side Frame (4 per dampener)
(Before serial #9211-08613)	
X06-346038	Thin Flanged Bushing (4 per dampener)
X06-103	Sealed Ball Bearing, Pivot (2 per dampener)

### Miscellaneous

XSA-9999	Metering Thumb Screw Assy. (Thumb screw, ratchet gear, set screw)
XSA-1121	Water Pan Assy. (w/ pan bolts)
X99-28	Water Pan Hose
X99-61	Wash Up Bottle
X88-27	Installation Manual

**FAX YOUR ORDER  
TO ACCEL TOLL FREE!  
1 (800) 365-6510**



#### Adjustments

- a. Pan to Metering
- b. Form to Metering
- c. Form to Plate

#### Roller Description

- P = Pan, Soft
- M = Metering, Hard
- O = Oscillator, Hard
- F = Form, Soft