

# MULTI 1250 Single & Dual Lever

## Frequently Used Part Numbers

### Rollers

All units after serial number 9108-04806 (Parent Only) have a soft rubber pan roller and a hard rubber metering roller. Old style rollers are no longer available.

- X07-0112 Form Roller, Soft (set collar 13-5043)
- X07-0311NS Pan Roller, Soft (set collar 13-5022)
- X07-0411 Oscillator Roller, Hard
- XSA-070212NS Metering Roller Assy., Hard (Roller, shaft, clip, bearing, collar)
- XSA-070507 Intermed. Assy., Soft (Roller, shaft, clip, collar, roll pin)

### Side Frame Assemblies

- XSA-010110P OPS Side Frame w/ bearings
- XSA-010110N NOPS Side Frame w/ bearings

### Gears

- XSA-03300540 Form Gear Assy. (Gear w/ clutch bearing)
- XSA-03300527 Pan Gear Assy. (Gear w/ clutch bearing)
- XSA-03300517U Upper Idler Gear Assy. (Gear w/ bushing, bolt)
- XSA-03300517L Lower Idler Gear Assy. (Gear, spool, bushing, bolt, washers)

### Side Frame Bearings


- (After serial number 9206-07319)  
X06-108 Sealed Ball Bearing (4 per dampener)
- (Before serial number 9206-07319)  
X06-346038 Thin Flanged Bushing (4 per dampener)

### Miscellaneous

- XSA-9903 Metering Thumb Screw Assy. (Thumb screw, ratchet gear, set screw)
- X09-0102 Compression Spring
- XSA-1118 Water Pan Assy. (w/ pan bolts)
- X99-28 Water Pan Hose
- XSA-9905 Water Bottle (w/ cap)
- X99-61 Wash Up Bottle
- X88-22 Installation Manual

FAX YOUR ORDER  
TO ACCEL TOLL FREE!  
1 (800) 365-6510

a. 1/8" to 5/32" (3-4mm)  
b. 1/8" to 5/32" (3-4mm)



#### Adjustments

- a. Metering to Pan
- b. Metering to Intermediate
- c. Form to Plate

#### Roller Description

- P = Pan, Soft
- M = Metering, Hard
- I = Intermediate, Soft
- O = Oscillator, Hard
- F = Form, Soft